

OVERVIEW

MULTI-Colour light models provide a choice of 8 exciting colours & 2 Multi-Colour programs with the flick of a switch!

Colours available are:

- | | | |
|----------------------------|-------------------------|----------------------------------|
| 1. Electric Blue | 4. Spring Lime | 7. Daylight White (4000k) |
| 2. Midnight Magenta | 5. Lagoon Green | 8. Warm White (3000k) |
| 3. Ruby Red | 6. Tropical Aqua | 9. Slow colour Blend |
| | | 10. Fast Colour Change |

OPERATING INSTRUCTIONS

- To change the colour of the light, simply turn your light **OFF** for **2 seconds** and then turn it back **ON**. This will signal the light to step through to the next colour. Colours will display in the order above, to select a desired colour, simply step through the colours until you find your desired selection.
- Your lights will automatically save your selected colour once the power has been turned **OFF** for more than 1 minute so the next time the lights are used, they will illuminate on the last colour selected.
- To reset or 'synchronise' your lights; with the power turned **ON**, turn the power **OFF/ON** once rapidly. This will put the lights into **RESET** mode (flashing **BLUE**), once this occurs turn the power **OFF**, wait 2 seconds & turn the power **ON**. Your lights should now be synchronised.

SYNCHRONISED INSTALLATION

When installing multiple lights; to ensure synchronisation and ease of operation all Lights must operate from a single switch.

